TEK750 Battery Replacement Instructions



The power of data. Optimized.

WARNING - EXPLOSION HAZARD: DO NOT REPLACE BATTERY PACK WHEN AN EXPLOSIVE ATMOSPHERE IS PRESENT. If necessary, remove monitor from tank and take to unclassified/ non-hazardous area before removing enclosure cover. USE ONLY BATTERIES PROVIDED BY ATEK!

Batte	e <mark>ry Replacement</mark> Remove four screws on ears of monitor.
2	Remove cover from bottom half of monitor. Take care as there is a cable connecting cover to bottom half.
3	Remove used battery from holder. Its easiest to remove one side first.
4	Replace with new battery. Note orientation of battery. Replace only with ATEK part # TEKRB02000.
5	Reposition O-ring so it sits on top of ledge around bottom half of monitor.
6	Line up divot on cover with TankAlert sticker on bottom half and press together.
7	Retighten screws.
Do not send used batteries to ATEK. Dispose of them in accordance with local guidelines and regulations.	
For questions or problems – Contact TankScan Technical Support,	

877-847-7226



WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

10025 Valley View Road, Ste. 190 Eden Prairie, MN 55344 U.S.A. www.atekaccess.com Email: CCT@tankscan.com Sales & Order Processing: 800-523-6996 Technical Support: 877-847-7226

©2021 ATEK Access Technologies, LLC. All Rights Reserved. TankScan images and marketing materials are protected by various patents, copyrights and/or trademarks. ATEK assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of ATEK are granted by the Company in connection with the sale of TankScan products, expressly or by implication.





Access the power of technology.